



THE AUTOMOTIVE LIGHTING BENCHMARK

2016+ CIVIC XB LED HEADLIGHTS INSTALL GUIDE

WARNING: By reading this document, you agree it is only to be used as an educational guide. Morimoto Lighting nor its dealers make guarantees on any finished results, nor are they to be held responsible for any damage, misuse, or personal injuries. If you are unable to clearly understand and adapt the information below, professional installation is recommended.






IMPORTANT: If your vehicle is equipped with anything but OEM turn signals (full assemblies, LED bulbs, or otherwise) in the tail lights or elsewhere: You may experience a hyper flash and/or problem with the sequential signal setting on these headlights. This is not a defect in the headlight, and caused by un-matched impedance with your original vehicle settings.

PARTS IDENTIFICATION

STANDARD PARTS

2x HEADLIGHT HOUSINGS





WIRING CONFIGURATION AND INSTALLATION



NOTE: There are two installation types of these housings: OEM LED and OEM HALOGEN. This guide covers both types.


OEM LED HEADLIGHT CARS

To adapt the headlights to utilize the factory LED headlight plugs, press the indicated button on the side of the input adapter and remove the adapter sub-harness. The remaining plug will match the factory LED headlight plugs.




OEM HALOGEN HEADLIGHT CARS

The connectors on the headlights will plug in to the stock plugs without modifications into their relevant positions.




NOTE: The auto-leveling system is not compatible with US vehicles. This connection can be skipped.

SEQUENTIAL TURN SIGNAL CONTROL



DISCONNECTED:
Sequential Turn Signal Function



CONNECTED:
Standard Turn Signal Function