


WARNING: By reading this document, you agree it is only to be used as an educational guide. Morimoto Lighting nor its distributors make guarantees on any finished results, nor are they to be held responsible for any damage, misuse, or personal injuries. Use at your own risk. If you are unable to clearly understand and adapt the information

PASSENGER / RH SIDE

DRIVER / LH SIDE



Route the DRL “Y-Harness” across the top of the radiator support and the fuse tap to the fusebox. Insert the fuse tap into position #35 as indicated.



In the infotainment display, turn the daytime running lights OFF.

